

Logo! 8 Getting Started version 1.0 by TK






1. Om Logo 8 modulen, basics om oppkobling.








Protection with automatic circuit-breaker, max. 16 A, characteristics B16, e. g. : Power circuit-breaker 5SX2 116-6 (if required)

Requirements for the network cable

Use a shielded Ethernet cable to connect to the Ethernet interface. To minimize electromagnetic interference, make sure you use a standard Category 5 shielded twisted-pair Ethernet cable with a shielded RJ45 connector on each end.

Connecting


You connect the FE terminal to earth ground, and connect a network cable to the Ethernet interface.



2. Oppsett av Logo

Logon må settes opp med IP-adresse, kan bruke 192.168.0.1 og oppover på PC og f.eks 192.168.0.31 og oppover på Logo, Subnet er da 255.255.255.0 på alt.

C:\Users\torkr\Desktop\VG2\IP adresser PC & Logo.xlsx




Med disse adressene kan du maks ha 256 enheter i nettverket.

192.168.0.0 - 192.168.0.255	255.255.255.0	256
192.168.0.0 - 192.168.1.255	255.255.254.0	512
192.168.0.0 - 192.168.3.255	255,255,252,0	1024

For å sette IP adresse på PC:


Gå til Windows merket nederst til venstre -> skriv inn Control Panel -> klikk control panel -> velg «vis små ikoner/detaljert» -> klikk nettverk -> klikk «change adapter settings» -> høyreklikk ethernet ikonet -> klikk egenskaper -> dobbeltklikk TCP/IPv4 -> sett statisk IP.



For å sette IP adresse på Logo, sett på power og gå inn i menyen, (obs! må være i stopp):

LOGO! 0BA8 provides a menu command for configuring network settings.

- 1. Switch LOGO! to programming mode.
- 2. Press ▲ or ▼ to move the cursor to "①".



- 3. Press OK to confirm "1".
- 4. Press ▲ or ▼ to move the cursor to "②".



5. Press **OK** to confirm "②". LOGO! displays the following view:





6. The display now shows the default IP address of your LOGO!. To change the setting, press OK. When the cursor appears in a flashing solid square, press ◀ or ▶ to move the cursor to a position where you want to modify the number, then press ▲ or ▼ to increase or decrease the number. To confirm your change, press OK.

3. Oppstart av Logo Software


LOGO!Soft Comfort







A typical LOGO! 8 network setup is shown below:



- Physical Ethernet connections
- ② Logical connection for communication between LOGO! and PC (by TCP/IP-based Ethernet)
- 3 Logical connections for S7 and Modbus communication between SIMATIC devices (with S7 protocol over TCP/IP)